

FRONT SUSPENSION		65-66		67		68-69		70		71-73	
3020	BUMPER , Upper Arm	3020-1A	5.95	3020-2A	7.95	3020-2A	7.95	3020-3A	6.25	3020-3A	6.25
3047	SHAFT KIT , Upper Arm	3047-1	37.50	3047-2	45.95	3047-2	45.95	3047-2	45.95	3047-2	45.95
3049	BALL JOINT , Upper Arm	4-Bolt 3049-1 ¹	17.95	4-Bolt 3049-1 ¹	17.95	4-Bolt 3049-1 ¹	17.95	3049-2	19.95	3049-2	19.95
				3-Bolt 3049-2 ²	19.95	3-Bolt 3049-2 ²	19.95				
3078	CONTROL ARM , Lower replacem't	3078-1A	54.95	3078-2A	56.95	3078-3A	45.95	3078-3A	45.95	3078-3A	45.95
3082	CONTROL ARM , Upper replacem't	3082-1B	79.95	3082-3B ³	76.95	3082-3B ³	76.95	3082-3B ³	76.95	3082-3B ³	76.95
3A130	TIE ROD END , Inner										
	6-Cylinder Manual RH or LH	3A130-2	33.95	3A131-3	30.95	3A131-3	30.95	3A131-4	27.95	3A131-5	47.50
	Power RH	3A130-2A	32.50	3A131-3	30.95	3A131-3	30.95	3A131-4	27.95	3A131-5	47.50
	LH	3A131-1B	32.50	3A131-3	30.95	3A131-3	30.95	3A131-4	27.95	3A131-5	47.50
	8-Cylinder Manual RH	3A131-2	29.95	3A131-3	30.95	3A131-3	30.95	3A131-4	27.95	3A131-5	47.50
	LH	3A131-2	29.95	3A131-3	30.95	Exc Boss 3A131-3	30.95	3A131-4	27.95	3A131-5	47.50
	Power RH	3A131-2	29.95	3A131-3	30.95	Boss 3A131-4	27.95				
	LH	3A131-1	44.50	3A131-3	30.95	3A131-3	30.95	3A131-4	27.95	3A131-5	47.50
						Exc Boss 3A131-3	30.95				
						Boss 3A131-4	27.95				
3A130	TIE ROD END , Outer										
	6-Cylinder Manual RH or LH	3A130-1	32.50	3A130-5	19.95	3A130-5	19.95	3A130-6	14.50	3A130-6	14.50
	Power RH	3A131-1A	32.50	3A130-5	19.95	3A130-5	19.95	3A130-6	14.50	3A130-6	14.50
	LH	3A130-2B	32.50	3A130-5	19.95	3A130-5	19.95	3A130-6	14.50	3A130-6	14.50
	8-Cylinder Manual RH	3A130-4	25.95	3A130-5	19.95	Exc Boss 3A130-5	19.95	3A130-6	14.50	3A130-6	14.50
	LH	3A130-4	25.95	3A130-5	19.95	Boss 3A130-6	14.50				
	Power RH	3A130-4	25.95	3A130-5	19.95	Exc Boss 3A130-5	19.95	3A130-6	14.50	3A130-6	14.50
	LH	3A130-3	37.95	3A130-5	19.95	Boss 3A130-6	14.50				
						Exc Boss 3A130-5	19.95	3A130-6	14.50	3A130-6	14.50
						Boss 3A130-6	14.50				
						Exc Boss 3A130-5	19.95				
						Boss 3A130-6	14.50				
3A187	BUSHING KIT , Strut Rod, 2 req'd	3A187-1	19.95								
	Midolayne -bush'gs only, 1 req'd	3A187-1A	16.95	3A187-2A	19.95	3A187-2A	19.95	3A187-2A	19.95	3A187-2A	19.95
3304	DRAG LINK ASSY										
	6-Cylinder Manual	3304-1A	49.95	3304-3	99.95	3304-3	99.95	3304-4A	124.95		
	8-Cylinder Manual	3304-1	59.95	3304-3	99.95	Exc Boss 3304-3	99.95	3304-4A	124.95		
	Power	3304-2	159.95	3304-4	99.95	Boss 3304-4A	124.95	Boss 3304-4A	124.95		
						Exc Boss 3304-4	99.95	N/A			
						Boss	CALL	Boss	N/A		
3310	SLEEVE , Drag Link Adjust										
	6-Cylinder Manual RH or LH	3310-3	19.95	3310-1	6.50	3310-1	6.50	3310-1	6.50	3310-1	6.50
	Power RH	3310-1	6.50	3310-1	6.50	3310-1	6.50	3310-1	6.50	3310-1	6.50
	LH	3310-2	16.95	3310-1	6.50	3310-1	6.50	3310-1	6.50	3310-1	6.50
	8-Cylinder Manual RH or LH	3310-1	6.50	3310-1	6.50	3310-1	6.50	3310-1	6.50	3310-1	6.50
	Power RH	3310-1	6.50	3310-1	6.50	3310-1	6.50	3310-1	6.50	3310-1	6.50
	LH	3310-2	16.95	3310-1	6.50	3310-1	6.50	3310-1	6.50	3310-1	6.50
3332	SEAL , Ball Stud	8 cyl. 3332-1	12.59	N/A		Boss 302 3332-2	4.25	3332-2	4.25	3332-2	4.25
3350	IDLER ARM BRACKET	3351-1	34.95								
3350/2/5	IDLER ARM ASSY										
	6-Cylinder Manual	3352-1	53.95	3350-2	61.75	3350-2	61.75	3350-2	61.75	3355-1	59.95
	Power	3352-2	154.95	3350-1	64.95	3350-1	64.95	3350-1	64.95	3355-1	59.95
	8-Cylinder Manual	3352-3 ⁵	51.95	3350-2	61.75	3350-2	61.75	3350-2	61.75	3355-1	59.95
	Power	3352-3 ⁵	51.95	3350-1	64.95	3350-1	64.95	3350-1	64.95	3355-1	59.95
3356	BUSHING , Idler Arm Upper, Manual	3356-2	9.95	3356-2	9.95	68 only 3356-2	9.95	N/A		N/A	
	Power	3356-1	9.95	3356-2	9.95	68 only 3356-2	9.95	N/A		N/A	
3356	BUSHING , Idler Arm Lower, Manual	N/A		N/A		3358-1	7.25	3358-1	7.25	3358-1	7.25
	Power	N/A		N/A		3358-2	7.50	3358-2	7.50	3358-1	7.25
3388	SEAT & BUSHING , Upper Arm	3388-1A	14.95	3388-1A	14.95	3388-1A	14.95	3388-1A	14.95	3388-1A	14.95
3468	STRUT , Lower Arm, RH	3468-1A	46.95	3468-2A	59.95	3468-4A	37.95	3468-4A	37.95	3468-4A	37.95
	LH	3468-1A	46.95	3468-2A	59.95	3468-5A	37.95	3468-5A	37.95	3468-5A	37.95

FOOTNOTES: ¹ Use w/original control arm ² Use w/replacement control arm ³ 3-bolt, 3082-2A for 4-bolt ⁵ Arm & Bushing, less bracket ⁶ Req's 3356-1 bushing

SUSPENSION SECTION INFO

Suspension chartspg 68 Suspension partspg 71
 Control armspg 72 Strut rodpg 72
 Shock absorberpg 72 Coil springpg 73
 Sway barpg 74 Leaf springpg 75
 Performance sway bar pg 76 Performance springs..pg 77
 Performance bushing pg 77 Perf. driveshaftpg 78
 Performance shocks...pg 78 Body stiffeningpg 79
 Performance steering pg 79 Suspension tuningpg 80
 Perf. susp. systems ..pg 80
 Some abbreviations found in this section:
 dia. diameter inc. includes
 LH drivers side MS Manual steering
 pc (s) Piece (s) PS Power steering
 Repl'mt Replacement req'd Required
 req's Requires RH passenger side
 w/ Used with W/o Used without



Grease Fitting Kit

This kit is the most effective way to eliminate the common squeaking problem the upper control arm bushings make when they dry up. Our special 2 piece 90° grease fittings and positioning wrench eliminate having to destroy your shock towers in order to inject grease into these bushings. Regular 90° fittings do not fit in the tight confines between the control arm and the shock tower wall. Kit includes 4 fittings, 1 special wrench and instructions. Will not fit 3082-1B and 3B imported arms.

Kit908-1 21.50

Grease Fittings (zerks)

Used throughout the suspension.
 See tool section for zerk tool 987-4.
 1/4"-28 straight
 Plated 87922-S41A 0.48
 Chrome 87922-S41C 0.75
 1/4"-28 90°
 Plated 87922-S42A 0.75
 Chrome 87922-S42C 0.75
 6mm 90°
 Use w/3082-1B and 3082-3B import arms.
 Plated 87922-S61A 0.50

